




# Horseballs™

## Tether Toss™ Game

- An Adult Game of Skill -

### Assembly Instructions

#### RAIL TARGET ASSEMBLY



#### This complete set includes:

- ♦ Two (2) Three Rail Target Sets
- ♦ Six (6) Tethered Ball sets,  
3 red, 3 blue
- ♦ One (1) scoreboard
- ♦ One (1) tote bag
- ♦ Plus: Game rules, assembly instructions and warranty.

#### **Note:**

We have made every effort to insure that the joints do not fit so tightly that they cannot be easily disassembled for transport. However, if you find that a joint is a bit loose, simply wrap the insert end with a piece of thin tape and that should correct the problem. A tight fitting joint can be lubricated with petroleum jelly for easier assembly. In the unlikely event that a cord separates from a ball, simply retie a knot at the end of the cord and press the knot back into the hole. For best results, heat the nylon knot, melting it slightly to secure the knot. Allow the cord to cool for a few seconds before reinserting. When disassembling, keep in mind that some parts are glued together at the factory. Avoid leaving game parts in the sun for long periods of time. Bright colors will fade with UV light exposure.

Be sure to save your Horseballs™ Game shipping carton! We've designed your tote to accommodate your game set, box and all. It will provide extra protection and give you easy access to the game parts.

*Visit us at:*

[www.horseballsgame.com](http://www.horseballsgame.com)

**for online shopping and additional information!**